



Cidex OPA or Ultizyme 28 Minor Spill (Less than 1 Gallon) Clean Up Procedures

1. **Notify** co-workers of the spill and **restrict access** to the affected area during clean up.
2. Open Spill Kit and put on **personal protective equipment**: nitrile gloves, chemical splash goggles, and gown.
3. Sprinkle the **neutralizer, Glute Out**, liberally over the spill (following instructions on Glute Out bottle). Neutralization process usually takes 5 minutes, occurring when the solution changes color:
 - Yellow Orange to dark Blue Black (for Cidex OPA)
 - Yellow Orange to Red Orange (for Ultizyme 28)
4. Place **absorbent pad** over the spill. Use the pad to pick up the spilled material.
5. Place the waste material in a plastic **waste bag** and dispose of in regular trash. Keep goggles for reuse if possible.
6. **Notify EH&S (4-6783)** about the spill: location, date, quantity spilled, and cause of spill.
7. **Reorder spill kit supplies** through PCI Medical (800.862.3394) or Lawson:
 - Refill Spill kit, including pads, gloves, gown and 1 bottle Glute Out (41899)
 - Refill Spill kit, including pads, gloves, gown and 4 bottles Glute Out (41900)
 - Case of 24 large bottles of Glute Out (41898)

For a major spill or if you need assistance:

In University Hospital: Call University Police, 911

In Hospital Satellite Facilities: Call Local Fire Department